



Thank you for your purchase of the Deoxzing Sample Kit™.

Please visit our Support Section on our website at www.Deoxzing.com to:

- See a live demonstration on how to apply the products
- Review the FAQ section

Anytime during the process you have questions, you can call our customer service team at 800-568-4773.

Please read these instructions before beginning. This will help you visualize the entire process, avoid mistakes, ensure a safe experience and produce quality results.

Before you begin:

SAFE and OPTIMAL WORKING CONDITIONS

This product must be applied in an open-air environment at a temperature above 60F (16C) degrees and not in direct sun if temperature is above 90F (32.2C) degrees. The vapors from the Deoxzing Final Finish™ and Deoxzing Accelerator™ are very flammable. No smoking! Do not allow anyone to approach who is smoking or may start smoking. Try to avoid working in a dusty environment, as this will affect the quality of the prep and the application steps. Dusty and or windy conditions may produce a less than optimal finish.

CONFIRM CONTENTS

Check the contents of your DRS™ Sample Kit against the inventory list below to ensure that you have everything you will need to begin and complete the process.

<u>Description</u>	<u>Quantity</u>
Deoxzing De-oxidizer™ in a 9 oz. container - half-filled	1
Deoxzing Restore & Shine Final Finish™- 4 ounces	1
Deoxzing Accelerator™ - a ½ ounce brown glass bottle	1
Nitrile Glove - one size fits all	1
Stirring Stick	1
Grey Scuff Pads - half sheet	1
Deluxe Applicator Pad	1
Application Tray (Beige)	1
Shop Towels – 4 sheets	1

Other items you will need that are not in your kit:

- Rinse bucket and access to fresh water.
- Masking tape.
- Drying cloth.
- Pair of pliers and a screwdriver (may be required to remove the caps and inner seals from the Deoxzing Final Finish and Accelerator).

TESTING THE PRODUCT PERFORMANCE

Tape or Mask off a 2 ft. by 3 ft. area of your craft. **Choose an area of your craft that is in the worst condition to test the product performance.**

The Process Is Easy As 1-2-3

1 REMOVE Old wax, scuff marks and the oxidation from the surface

MIX - Take the Deoxzing Deoxidizer™ 9 oz. Cylinder Bottle that contains 4 ounces of the Deoxzing De-oxidizer™ and fill the balance with water. Place the pump spray nozzle onto the bottle and shake well.

SPRAY the Deoxidizer on the selected demo area. Use the provided Grey Scuff Pad to scrub this section until the oxidation is removed. During this de-oxidation process it is normal to see white residue and a little of the craft color collect on the grey scuff pad and in the rinse bucket, especially if your craft is severely oxidized.

WARNING: If your craft has old or worn decals and/or logos that you want to keep, mask them. The Deoxzing formula could remove or deface them during the de-oxidation process. Do not scrub these areas very hard.

2 INSPECT The completed deoxidized surface

Please check the work that you have just completed; use the shop towels provided to go over the prepared surface to ensure that you have removed all of the oxidation. A properly prepared surface will appear dull and hazy, and there should be no white residue on the shop towel. If you are picking up any white, milky and chalky residue you must repeat the de-oxidizing process.

IMPORTANT: Please take your time, removing the oxidation is the most important step in restoring and returning the shine to the surface of your craft. Repeat the DEOXIDIZING (removal process) where necessary for the best results.

STOP AND CHECK THE WEATHER CONDITIONS: Do not apply the *activated* Deoxzing Restore & Shine Final Finish™ in the rain or if you believe that the weather conditions may change within two hours after the product has been applied; wait for dry conditions.

3 APPLY The Final Finish

MIX - Pour the Deoxzing Restore & Shine Final Finish™ and the ½ ounce of Deoxzing Accelerator™ into the provided Beige Application Tray. Use the stick that is provided in the kit to mix the products by stirring the blend for ten seconds. The Final Finish is now **activated** and must be applied within 5 minutes on the selected surface. Any unused activated Final Finish will turn to a solid after sitting overnight. The remaining product can then be discarded as a solid waste.

READY TO APPLY:

- Put on the Nitrile glove provided in the kit.
- Dip the edge of a provided Deluxe Applicator Pad™ into the tray of the activated Deoxzing Restore & Shine Final Finish™. Slide the applicator across the dimples of the tray to remove the excess product.
- Using normal pressure, in a 2 - 3 foot (60-90 cm) section using horizontal strokes, move the wet applicator pad across the surface of the chosen area. You may see small runs on the first pass, **do not be alarmed**, you will smooth them out on your next pass. Make your next horizontal stroke below the first stroke and overlap a portion of the first stroke.

Product Tips

- ✓ The key is to maintain a nice wet coat. As you are applying the product make sure you keep enough product on the applicator pad so your coverage is **wet, but not runny**.
- ✓ The product has a tacky feel to it by design, this allows it to absorb into the surface of the craft and leave a nice glossy shine with no film build-up. It should be dry to the touch in approximately 30 minutes when working in outside conditions at or above 60F (16C) degrees.

CONGRATULATIONS!!! Enjoy the beautiful finish up to 12 months from the date of application.

Less Maintenance. More Fun.